

ELECTRICAL COVER PLATES

M35	One Duplex Two Toggle Switch		p. 72
M36	Two Blank Box Mount		p. 72
M37	Three Blank Box Mount		p. 72

ACCESS KEYS


M51	Stainless steel access key opens emergency button on locks equipped with the M14 Privacy Turn.	p. 101
-----	--	--------



EXTENSION PLATES

Extension Plate installed between Lock Covers 1483 and 1484 and face of door to enclose extension ring of deadbolt.

M82		p.21
-----	--	------



SCHMATIC
NBS